




Kodak Easyshare Z981 Back Cover Replacement

This guide will explain in detail how to replace the back cover of the Kodak Easyshare Z981.

Written By: Olivia Boyna





TOOLS:

- [Phillips #00 Screwdriver](#) (1)
- [iFixit Opening Tools](#) (1)



PARTS:

- [Kodak Easyshare Z981 Replacement Back Panel](#) (1)

Step 1 — Back Cover



- Remove screws using a [00 Phillips-Head](#) screwdriver:
 - Eight (8) **3mm** screws on the lower portion of the camera
 - Four (4) on the bottom of the camera
 - Four (4) inside the battery cover

Step 2




- Start from a corner and gently remove the bottom cover of the camera.
 - ⓘ The cover will easily lift off without much pressure necessary.

Step 3



- Use a [Phillips #00 Screwdriver](#) to remove the **4 mm** screws from each side of the back cover of the camera.
 - Two (2) screws are located in the left side of the device
 - Two (2) screws are located in the right side of the device

Step 4



- Use a [Plastic Opening Tool](#) to remove the back of the camera and pull gently on the cover to remove the cover

⚠ Start from one corner and apply light pressure with the tool.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-23 09:49:02 AM.